

30-MIN JOINT PLASTER

**PRODUCT NAME**

GYPS' JOINT 30 MIN

STANDARD

UNE - EN 13963

DESCRIPTION

GYPS' JOINT 30 MIN is a powdered plaster for joints in plasterboard constructions or similar.





30-MIN JOINT PLASTER

GYPS' JOINT 30 MIN

METHOD OF APPLICATION

PREPARATION:

- The surface must be absorbent.
- The sheets of laminated plasterboard must be firmly fixed to the profiles, be dry, and be free of any dust and any loose pieces of possible contaminants.

PRODUCT PREPARATION:

- Sprinkle GYPS' JOINT 30 MIN into the correct amount of clean water for the quantity of product to be mixed.
- Leave it to stand for around 2 minutes to let the plaster hydrate correctly.
- Mix vigorously, either manually or mechanically, until you have a good consistency.

APPLICATION:

- Apply with a spatula or trowel to the edges of the boards (maximum 1mm of product) and apply the paper tape.
- Next, 'iron' it down by running the spatula over it, removing any excess material. Rejointing is normally done with two coats of the product. Once the first coat has set, apply the second and let it set. It is important to let the first coat of plaster set well before applying the second.
- If necessary, apply a third, optional coat once the previous one has set.
- Afterwards, sand lightly.



ADVANTAGES

Simple application

Excellent quality finish

No shrinkage

TECHNICAL DATA

USE WITHIN:	30 minutes
MIXTURE STANDING TIME:	2 minutes
WATER-PRODUCT RATIO:	10 - 11 l/sack
APPLICATION TEMPERATURE:	5 °C - 40 °C

PACKAGING



25 KG/SACK



48 SACKS/PALLET



25 TN



STORAGE AND PRESERVATION

- Store the product on a flat surface and never outdoors. Keep dry and out of direct sunlight.
- Use within 12 months of the date of manufacture.

LEGAL NOTICE: This information, in particular the recommendations relating to product application and the technical data, is based on our experience and current knowledge as well as the suggested uses and common applications of our products, and is subject to the final conditions of the site or the application of the products. GYPROD is not liable for the use of the products by third parties, or for the results obtained.
The GYPROD quality guarantee is limited exclusively to the product supplied.